

Basic Installation

1. Plug a coax cable from the wall into the top “coax in” port.
2. Plug the RCA cable provided into the 3 colored RCA ports on your set top box and also into your TV.
3. Plug the power cord into a power outlet, insure the main power switch on the back of the box is on, and turn on the box with the power button on the front or with the provided remote.
4. You will probably need to change the input on your TV. While each TV varies, this is usually found in a menu under INPUT. Some TVs have each port labeled (HDMI, Cable, Input 1, etc.) You may need to test each input until you see the picture on your screen.

When box is not in use, turn it off to prevent loss of sound. If sound stops working, power cycle the box by turning off the main power switch in the back for 30 seconds.

Before reporting problems please insure that:

- Your box is set to factory settings (Menu, magnifying glass, Factory settings, yes)
- Your box has the latest update (Menu, magnifying glass, S/W Upgrade by OTA, start)
- You run an auto scan (Menu, magnifying glass, auto scan, search)

