

Basic Installation:

1. Plug a coax cable from the wall into the top “cable in” port.
2. Plug an external hard drive into the “USP” port.

Option 1

3. Plug the RCA cable provided into the 3 colored RCA ports on your set top box and also into your TV.

Option 2

3. Plug an HDMI cable in HDMI port in your set top box and also into your TV.
4. Plug the power cord into a power outlet, and turn the box on with the power button on the front or with the provided remote.
5. You will probably need to change the input on your TV. While each TV varies, this is usually found in a menu under INPUT. Some TVs have each port labeled (HDMI, Cable, Input 1, etc.) You may need to test each input until you see the picture on your screen.

Before reporting problems please insure that:

- **Your box is set to factory settings:** Menu, settings, version, Reset to Factory Default
- **You run an auto scan:** Menu, settings, tuner, auto scan (this will take up to 10 minutes to scan)

Packaging:

- Remote control
- Batteries for the remote control
- HDMI Cord
- RCA Cable
- Power Adaptor
- Pico Digital VMX1-1 Quick Install Guide
- Pico Digital VMX1-1 Recording Instructions

